

## **Transom Instructions**

From Outside of Hull

Install 1 bolt with S.S. washer in top hole through hull and S.S. hinge. Loosely fasten with nut.

Install 1 bolt with S.S. washer and 1 rubber washer in bottom hole, through hull and S.S. hinge.

Loosely fasten with nut. Add remaining nuts and bolts making sure the bottom 2 holes on each and have the rubber washers. Proceed to tighten all nuts and bolts.