


Bow Cover Instructions

Locate the small hole just under the gunnel tube approximately 1" past the edge of the black flotation foam on each side of your boat. (See Picture 1)

Please note: If your boat does not have these 2 holes that is where you will need to drill a ¼ in diameter hole for the hook of the bungee.

Take one bungee cord in each hand and slip the bow cover over the bow. (See Picture 2)
Then stretch each bungee so the hook will insert to each hole. (See Picture 3)



Picture 1



Picture 2



Picture 3

Porta-Bote International
8118 Arroyo Circle
Gilroy, CA 95020
(408)842-1322

